

DE LA RECHERCHE À L'INDUSTRIE

cea



[www.cea.fr](http://www.cea.fr)

# NEW DEVELOPMENTS OF AUTORADIOGRAPHY TECHNIQUE TO IMPROVE ALPHA AND BETA MEASUREMENTS FOR DECOMMISSIONING FACILITIES

PASCAL FICHET, C MOUGEL, Y DESNOYERS, P SARDINI, H WORD

DEN – SERVICE D'ETUDES ANALYTIQUES ET DE RÉACTIVITÉ DES SURFACES

(SEARS), CEA, UNIVERSITÉ PARIS-SACLAY, F-91191, GIF SUR YVETTE, FRANCE

MAIL: [PASCAL.FICHET@CEA.FR](mailto:PASCAL.FICHET@CEA.FR)

WORKSHOP ON "CURRENT AND EMERGING METHODS FOR OPTIMISING SAFETY AND

EFFICIENCY IN NUCLEAR DECOMMISSIONING"

FEBRUARY 8 TH 2016

## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions

## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions

# CONTEXT: MANAGEMENT OF NUCLEAR WASTES

↳ **Who?** The National Radioactive Waste Management Agency **ANDRA** is in charge of the long-term management of radioactive wastes in France



⇒ Classification of radioactive wastes as a function of their management

<b>Activity - Half-life</b>	<b>Very short-half-life &lt; 100 days</b>	<b>Short half-life ≤ 31 years</b>	<b>Long half-life &gt; 31 years</b>
Very low level waste	Management by radioactive decay	Surface disposal facility (CSTFA Aube facility)	
Low level waste		Surface disposal facility (CSFMA Aube facility)	Near-surface disposal facility being studied
Intermediate level waste			Deep disposal facility at 500 meters being studied
High level waste		Deep disposal facility at 500 meters being studied	

# CONTEXT: ORIGIN OF LOW AND INTERMEDIATE LEVEL NUCLEAR WASTES

Nuclear power industry (EDF, AREVA)




Hospitals

Nuclear research centers (CEA)

# NUCLEAR WASTES ANALYSIS REQUIRED BY AUTHORITIES

👉 **Why? ANDRA** requests a characterization of nuclear wastes and specifies acceptance criteria for packages that waste producers have to respect




👉 **Why? Characterization is one of the essential step in decommissioning projects**



# ANALYTICAL CAPABILITY OF NETLAB

**NetLab** associated to NetLab = A CEA network of analytics and experimental tools (laboratories located on CEA sites) to assist nuclear operators during characterization programs associated to dismantling process.



**High Level**

**Intermediate level**

**Low level**



# LASE LABORATORY, FRANCE

*(25 km at the south of Paris)*



- ❑ Different characterization techniques for low and intermediate level wastes.
- ❑ Destructive analysis (sample = 1 g)
- ❑ Radiochemistry
- ❑ Alpha, Gamma, LSC
- ❑ Elemental analysis
  
- ❖ In situ technique: **Autoradiography**





# CHARACTERIZATION OF LOW AND INTERMEDIATE LEVEL NUCLEAR WASTES

⇒ Mission of Analytical support to facilities Laboratory at CEA-Saclay

## ANALYSIS OF ELEMENTS (RADIOACTIVE OR NOT ) PRESENT AT TRACE LEVEL IN VARIOUS MATRICES

Chemical and radiological  
characterization  
of radioactive materials

Toxic elements, organic ligands, TOC,  
anions, cations

Wipes, technological wastes (tissues,  
gloves), concretes, ion exchange resins  
embedded in organic polymers, metals,  
muds, sludges, oils...

Radionuclides determined after  
radiochemistry ( $A \sim 0.1 \text{Bq.g}^{-1}$ )

$^3\text{H}$ ,  $^{14}\text{C}$ ,  $^{36}\text{Cl}$ ,  $^{55}\text{Fe}$ ,  $^{59}\text{Ni}$ ,  $^{63}\text{Ni}$ ,  $^{90}\text{Sr}$ ,  $^{93}\text{Mo}$ ,  $^{93}\text{Zr}$ ,  
 $^{93\text{m}}\text{Nb}$ ,  $^{94}\text{Nb}$ ,  $^{108\text{m}}\text{Ag}$ ,  $^{121\text{m}}\text{Sn}$ ,  $^{129}\text{I}$ ,  $^{151}\text{Sm}$ ,  $^{241}\text{Pu}$ ,  
 $^{238}$  et  $^{240}\text{Pu}$ ,  $^{239}\text{Pu}$ ,  $^{241}\text{Am}$ ,  $^{243}\text{Am}$ ,  $^{232}\text{U}$ ,  $^{234}\text{U}$ ,  
 $^{235}\text{U}$ ,  $^{238}\text{U}$



⇒ Main Radionuclides that must be investigated in priority

❖ Easy to measure:

❖ gamma emitters

❖ Difficult to measure

❖ Alpha emitters

❖ Beta emitters


- H-3
- C-14
- Cl-36
- Sr-90

# CHARACTERIZATION IS VERY IMPORTANT FOR D&D PROJECTS

Destructive techniques need less than 1 g of sample for digestion process



Lots of Radwastes must be characterized




Innovation is required for in situ techniques, for techniques allowing a better sampling process

## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions



## Radiography

Source



Detector

## Autoradiography




Detector

Interests of biologists: H, C, S, ... radionuclides  
difficult to measure




Screens can be reused hundreds of times




# DA TECHNIQUE

- Semi quantitative values are achievable.



- Repeatability corresponds only to a few percent

Same H-3 analysis




## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions

# SAMPLING FOR FINAL CONTROL TO ASSESS THE CLEARANCE LEVEL

Decommissioning requires characterization at very low level. Requirement of in situ technique to improve sampling process. 1 g sample needed for destructive analysis.

## Decommissioning and dismantling




Mélusine, Grenoble





# Sampling process on floor

A grid corresponding to 70 screens = 5 m<sup>2</sup>



Radioactivity  
image, here  
C-14  
Localisation  
of the sample  
for destructive  
analysis is  
clear

Autoradiography with raw images




# OTHER EXAMPLE FOR URANIUM MEASUREMENTS




Screen on surface



1.8 m



0.3 m



« Hot » spots clearly appears



Maximum activity found around 6 Bq/cm<sup>2</sup>

Contamination shape is also an important parameter for stakeholders.



# OTHER EXAMPLE FOR TRITIUM SAMPLING

## Current development: geostatistical approach




Current investigation rate:  
2 weeks / 100 m<sup>2</sup>


Conclusion:

Contamination accurate location


Representative and limited sampling enabling



Zoning




Effective mapping



Geostatistical mapping

+



Variance plot

## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- **Digital Autoradiography in support of sampling processes**
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions


# SAMPLING PROBLEMS FOR RADIOCHEMICAL ANALYSIS




Caisse 95430




Echantillon 92886



Caisse 95434



Echantillon 95563



SAC 2 95485



How to collect 1g or even less?




## Preparation of homemade standards for beta analysis: CONCRETES

Concrete spiked at the beginning of the preparation of the cement



Can be spiked with numerous radionuclides H-3, C-14, Gamma emitters...)



**Homogeneity on concrete surface (here H-3 and C-14)**



Raw signal




Numerical treatment to evaluate the homogeneity by digital autoradiography




# EXAMPLE OF TRITIATED WASTES

Sampling process for **tritiated** wastes

Autoradiography




Destructive measurement of H-3 is done by pyrolysis followed by Liquid Scintillation Counting (LSC)



Sample = 1 g

# EXAMPLE OF WASTES CONTAINING URANIUM

Only 3 wipes among 7 contained Uranium.




After studies with a destructive method: wipe digestion followed by alpha spectrometry and/or ICP-MS, detection limit was determined at **0.2 Bq/wipe** for Uranium (more sensitive than alpha spectroscopy).

# HOW TO COLLECT SAMPLES ON CORES


After surface analysis on D&D sites, determination of 3D contamination



Core made of concrete containing C-14



Activity on surface



Interesting sampling



Activity in depth




Image in real scale

# HOW TO COLLECT SAMPLES ON CORES WITH HIGH AMOUNT OF RADIOACTIVITY ?

Study of alumina beads containing I-129 located inside a plastic tube



Plastic deposited on a film for **15 minutes**



DA as efficient solution for sampling process



## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory, FRANCE
- Digital Autoradiography Technique
- Radionuclide mapping using geostatistics
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity and new researches
- Conclusions





# IMPROVEMENT OF SELECTIVITY

## Screen stacking method (1/2)



<sup>90</sup>Sr/<sup>90</sup>Y sealed source



### Intermediate precision

example of <sup>90</sup>Sr/<sup>90</sup>Y:

2 point sealed sources from LASE


5 sealed filtrates from LASE

1 point sealed source from INSTN

2 area sources from INSTN


$$S_2/S_1 = 33 \pm 6 \%$$

$$S_3/S_2 = 59 \pm 6 \%$$



# IMPROVEMENT OF SELECTIVITY



## Screen stacking method (2/2)



$\beta$

Radionuclides "signatures"

$\beta+\gamma, \alpha+X$



$\alpha$

## ❑ Screen technique

Very easy to use, lots of applications



The information comes after the exposure time



## ❑ CCD development




Technique coming from biological applications

Main advantage: commercial systems already exist

Detection is obtained simultaneously



# FIRST EXAMPLE



Trace amount of uranium: around 1 Bq/cm<sup>2</sup>

## Overview

- Context and LASE laboratory : Analytical Support to Facilities Laboratory
- Digital Autoradiography Technique
- Digital Autoradiography in support of sampling processes
- Digital Autoradiography: improvement of the selectivity
- **Conclusions**

- ❑ Digital Autoradiography was used first because the technique is sensitive to difficult to measure radionuclides.
- ❑ Geostatistics methods can be very useful to interpret high amount of data and to provide extrapolated data.
- ❑ Autoradiography appears to be a very interesting technique for sampling processes.



- ❑ Different developments are currently in R&D for mapping applications, to improve the sensitivity, to try to find possibilities to improve the selectivity and to develop other devices
  
- ❑ The LASE laboratory participates to numerous intercomparison tests where no sampling problem is usually encountered however it is totally different for radiochemical analysis required for solid radwastes matrices.

# Thank you for your attention



Commissariat à l'énergie atomique et aux énergies alternatives  
Centre de Saclay | 91191 Gif-sur-Yvette Cedex  
T. +33 (0)1 69 08 26 27 | F. +33 (0)1 69 08 43 23

Etablissement public à caractère industriel et commercial | RCS Paris B 775 685 019